


Counterfeit Detection System


LAMP REPLACEMENT INSTRUCTIONS

Replacing the UV Lamp (top light)


1. Remove black plastic clamps from both sides of bulb and bulb housings.



2. Turn old UV lamp until pins line up with housing slot.




3. Pull out to remove old lamp.



4. Replace with new lamp by repeating steps 1 to 3 in reverse.


Replacing the White Fluorescent Lamp (bottom light)

1. Remove bottom plate of unit, unscrewing four corners of plate.



2. Turn old lamp until pins line up with housing slot.

3. Pull out to remove old lamp. Replace with new lamp, repeating steps 2 and 3 in reverse.



4. Reinstall bottom plate of unit.